



**11382** Plug for ASR-cylinder clip / set of 6



**8315-0355**  
V-Stays BLUEMELS 3.0  
Incl. 3 x assembly material and  
stainless steel stays 3.0,  
**355 mm**. Set of stays for front  
and rear wheel.



**8315-0380**  
V-Stays **380 mm**




**11366** Stays for suntour



**10188** Clipbag



**11380** Protector SPB 3,0 mm 10  
Stay fastening / set of 10



**10190** Frame mounting kit